

DIAGRAM

ELECTRIC
HYDRAULIC

ASCO DRY ICE PELLETIZER P15 EVO

from SN 26-031-006
ascoco2.com



Kontakt / Contact:

Hauptsitz / Head Office

ASCO Kohlensäure AG / ASCO CARBONDIOXIDE LTD.
Hofenstrasse 19, CH-9300 Wittenbach
T +41 71 466 80 80
info@ascoco2.com / ascoco2.com
MwSt / VAT-ID: CHE-107.889.692 MWST

Betriebsstätte / Production Site

ASCO Kohlensäure AG
Sprudelstrasse 3, DE-53557 Bad Honningen
T +49 2635 92 534-0
info@ascoco2.com / ascoco2.com
VAT-ID: DE196946952

Subsidiary USA

ASCO CARBON DIOXIDE INC.
80-4 Industrial Loop North, Orange Park, FL 32073
T +1 904 374 9590 / Toll free +1 877 633 0996
usa@ascoco2.com / ascoco2.com/us

Sitz: Wittenbach | Handelsregister: Kanton St. Gallen | Firmen-Nr.: CHE107.889.692 | Präsident des Verwaltungsrates: Adolf Walth | Geschäftsleitung: Ralph Spring (MD)
Seat: Wittenbach | Commercial register of canton: St. Gallen | Company No.: CHE107.889.692 | Chairman of the Board: Adolf Walth | Management: Ralph Spring (MD)

ELECTRIC



WARNING

Risk of injury from electric power!

Changes on the electrical installation on your own are prohibited.

Changes on the electrical installation, on the program or on its parameters can cause serious damages to the machine and its environment.

Any change on the control or at the program which is not performed by an ASCO-technician leads to a loss of warranty.



SCHWEIZ
ASCO KOHLENSÄURE AG
Hofenstrasse 19
9300 Wittenbach
Schweiz
T +41 71 466 8080
info@ascoco2.com

SWITZERLAND
ASCO CARBON DIOXIDE LTD
Hofenstrasse 19
9300 Wittenbach
Schweiz
T +41 71 466 8080
info@ascoco2.com

USA
ASCO CARBON DIOXIDE INC.
80-4 Industrial Loop North
Orange Park, Florida 32073
USA
T +1 (904) 374-9590
usa@ascoco2.com

Project-Nr.:

Project description:

Dry Ice Pelletizer
P15 EVO / P28 EVO CE US V531

Plant designation:

Degree of protection:
Power input:
Control voltage:
Rotary field:
Pre-fuse:
short-circuit proof Icp:
Input lead:
Operating Temperature Range:

IP 54
CE: 3x400 VAC / 50 Hz / 25 A -- US: 3x480 VAC / 60 Hz / 25 A
24 VDC
Clockwise
C 25A
6kA
4G4mm² at 30°C see cross-section calculation page 4.1
5-35°C

Table of contents

Plant	Mounting location	Page	Page description	Edited by	Date	Remarks
=P15(0)_P28(0)	+SS01	57	PLC overview		11.05.2026	
=P15(0)_P28(0)	+SS01	58	PLC overview		11.05.2026	
=P15(0)_P28(0)	+SS01	60	Operation / control panel		11.05.2026	
=P15(0)_P28(0)	+SS01	61	Remote maintenance module		11.05.2026	
=P15(0)_P28(0)	+SS01	63	Signal tower		11.05.2026	
=P15(0)_P28(0)	+SS01	65	Interface 1 Emergency stop		11.05.2026	
=P15(0)_P28(0)	+SS01	66	Interface 1 digital inputs		11.05.2026	
=P15(0)_P28(0)	+SS01	67	Interface 1 digital outputs		11.05.2026	
=P15(0)_P28(0)	+SS01	68	Interface 1 analog inputs		11.05.2026	
=P15(0)_P28(0)	+SS01	69	Interface 1 ASCO CO2 detector		11.05.2026	
=P15(0)_P28(0)	+SS01	70	Interface 1 conveyor belt		11.05.2026	
=P15(0)_P28(0)	+SS01	110	Plant part 1 Sensors		11.05.2026	
=P15(0)_P28(0)	+SS01	120	Plant part 1 sensors analog		11.05.2026	
=P15(0)_P28(0)	+SS01	130	Plant part 1 Valves		11.05.2026	
=AU501	+SS01	1	Parts list		12.05.2026	
=AU501	+SS01	1.1	Parts list		12.05.2026	
=AU501	+SS01	1.2	Parts list		12.05.2026	
=AU501	+SS01	1.3	Parts list		12.05.2026	
=AU501	+SS01	1.4	Parts list		12.05.2026	
=AU501	+SS01	1.5	Parts list		12.05.2026	
=AU502	+SS01	1	Summarized parts list		11.05.2026	
=AU502	+SS01	1.1	Summarized parts list		11.05.2026	
=AU502	+SS01	1.2	Summarized parts list		12.05.2026	
=AU502	+SS01	1.3	Summarized parts list		12.05.2026	
=AU502	+SS01	1.4	Summarized parts list		12.05.2026	
=AU502	+SS01	1.5	Summarized parts list		12.05.2026	
=AU502	+SS01	1.6	Summarized parts list		12.05.2026	
=AU502	+SS01	1.7	Summarized parts list		12.05.2026	

Table of contents

Plant	Mounting location	Page	Page description	Edited by	Date	Remarks
=AUS02	+DR	1	Summarized parts list		11.05.2026	
=AUS02	+DR	1.1	Summarized parts list		11.05.2026	
=AUS02	+EXT	1	Summarized parts list		11.05.2026	
=AUS02	+EXT	1.1	Summarized parts list		11.05.2026	
=AUS02	+EXT	1.2	Summarized parts list		11.05.2026	
=AUS02	+EXT	1.3	Summarized parts list		11.05.2026	
=AUS03		1	Cable diagram		11.05.2026	
=AUS03		1.1	Cable diagram		11.05.2026	
=AUS03		1.2	Cable diagram		12.05.2026	
=AUS03		1.3	Cable diagram		11.05.2026	
=AUS03		1.4	Cable diagram		11.05.2026	
=AUS03		1.5	Cable diagram		11.05.2026	
=AUS03		1.6	Cable diagram		11.05.2026	
=AUS04		1	Cable overview		11.05.2026	
=AUS05		1	Terminal-strip overview		12.05.2026	
=AUS06		1	Terminal diagram =P15(i)_P28(i)+SS01-10X1		12.05.2026	
=AUS06		2	Terminal diagram =P15(i)_P28(i)+SS01-15X1		11.05.2026	
=AUS06		3	Terminal diagram =P15(i)_P28(i)+SS01-16X1		11.05.2026	
=AUS06		4	Terminal diagram =P15(i)_P28(i)+SS01-40X1		11.05.2026	
=AUS06		5	Terminal diagram =P15(i)_P28(i)+SS01-41X1		11.05.2026	
=AUS06		6	Terminal diagram =P15(i)_P28(i)+SS01-41X3		11.05.2026	
=AUS06		7	Terminal diagram =P15(i)_P28(i)+SS01-41X5		11.05.2026	
=AUS06		8	Terminal diagram =P15(i)_P28(i)+SS01-41X7		11.05.2026	
=AUS06		9	Terminal diagram =P15(i)_P28(i)+SS01-65X1		11.05.2026	
=AUS06		10	Terminal diagram =P15(i)_P28(i)+SS01-66X1		11.05.2026	
=AUS06		11	Terminal diagram =P15(i)_P28(i)+SS01-68X1		11.05.2026	
=AUS06		12	Terminal diagram =P15(i)_P28(i)+SS01-69X1		11.05.2026	
=AUS06		13	Terminal diagram =P15(i)_P28(i)+SS01-70X1		11.05.2026	

Table of contents

Plant	Mounting location	Page	Page description	Edited by	Date	Remarks
=AUS06		14	Terminal diagram =P15()_P28() +SS01-110X1		11.05.2026	
=AUS06		15	Terminal diagram =P15()_P28() +SS01-120X1		11.05.2026	
=AUS06		16	Terminal diagram =P15()_P28() +SS01-120X5		11.05.2026	
=AUS06		17	Terminal diagram =P15()_P28() +SS01-120X7		11.05.2026	
=AUS06		18	Terminal diagram =P15()_P28() +SS01-120X9		11.05.2026	
=AUS06		19	Terminal diagram =P15()_P28() +SS01-130X1		11.05.2026	
=AUS06		20	Terminal diagram =P15()_P28() +SS01-130X5		11.05.2026	
=AUS06		21	Terminal diagram =P15()_P28() +SS01-40XT5		12.05.2026	
=AUS07		1	Terminal line-up diagram =P15()_P28() +SS01-10X1		12.05.2026	
=AUS07		2	Terminal line-up diagram =P15()_P28() +SS01-15X1		11.05.2026	
=AUS07		3	Terminal line-up diagram =P15()_P28() +SS01-16X1		11.05.2026	
=AUS07		4	Terminal line-up diagram =P15()_P28() +SS01-40X1		11.05.2026	
=AUS07		5	Terminal line-up diagram =P15()_P28() +SS01-41X1		11.05.2026	
=AUS07		6	Terminal line-up diagram =P15()_P28() +SS01-41X3		11.05.2026	
=AUS07		7	Terminal line-up diagram =P15()_P28() +SS01-41X5		11.05.2026	
=AUS07		8	Terminal line-up diagram =P15()_P28() +SS01-41X7		11.05.2026	
=AUS07		9	Terminal line-up diagram =P15()_P28() +SS01-65X1		11.05.2026	
=AUS07		10	Terminal line-up diagram =P15()_P28() +SS01-66X1		11.05.2026	
=AUS07		10.1	Terminal line-up diagram =P15()_P28() +SS01-66X1		11.05.2026	
=AUS07		11	Terminal line-up diagram =P15()_P28() +SS01-68X1		11.05.2026	
=AUS07		12	Terminal line-up diagram =P15()_P28() +SS01-69X1		11.05.2026	
=AUS07		13	Terminal line-up diagram =P15()_P28() +SS01-70X1		11.05.2026	
=AUS07		14	Terminal line-up diagram =P15()_P28() +SS01-110X1		11.05.2026	
=AUS07		15	Terminal line-up diagram =P15()_P28() +SS01-110X3		11.05.2026	
=AUS07		16	Terminal line-up diagram =P15()_P28() +SS01-120X1		11.05.2026	
=AUS07		17	Terminal line-up diagram =P15()_P28() +SS01-120X5		11.05.2026	
=AUS07		18	Terminal line-up diagram =P15()_P28() +SS01-120X7		11.05.2026	
=AUS07		19	Terminal line-up diagram =P15()_P28() +SS01-120X9		11.05.2026	

Cable cross section			
Cross-section:	Current load:	Cross-section:	Current load:
0.5mm ²	3 A	AWG 24 (0.21mm ²)	2 A
0.75mm ²	4 A	AWG 22 (0.33mm ²)	4 A
1.0mm ²	6 A	AWG 20 (0.52mm ²)	6 A
1.5mm ²	10 A	AWG 19 (0.65mm ²)	7 A
2.5mm ²	16 A	AWG 18 (0.82mm ²)	8 A
4.0mm ²	20 A	AWG 16 (1.31mm ²)	10 A
6.0mm ²	25 A	AWG 14 (2.08mm ²)	20 A
10mm ²	40 A (35A)	AWG 12 (3.32mm ²)	25 A
16mm ²	63 A (50A)	AWG 10 (5.26mm ²)	40 A
25mm ²	80 A	AWG 8 (8.35mm ²)	55 A
35mm ²	100 A	AWG 6 (13.30mm ²)	80 A
50mm ²	125 A	AWG 4 (21.15mm ²)	105 A
70mm ²	160 A	AWG 3 (26.67mm ²)	120 A
95mm ²	200 A	AWG 2 (33.63mm ²)	140 A
120mm ²	225 A	AWG 1 (42.41mm ²)	165 A
150mm ²	250 A	AWG 0 (53.48mm ²)	195 A
185mm ²	300 A	AWG 2/0 (67.43mm ²)	225 A
240mm ²	350 A	AWG 3/0 (85.03mm ²)	260 A
		AWG 4/0 (107.2mm ²)	300 A
Cross-section calculation			
Ambient temperature		Conversion factor	
30°C	86°F	1.00	
40°C	104°F	0.87	
45°C	113°F	0.79	
55°C	131°F	0.62	

Copper busbar blank			
Cross-section:	Current load:		
12 x 2 mm	123 A		
15 x 2 mm	143 A		
15 x 3 mm	197 A		
20 x 2 mm	189 A		
20 x 3 mm	237 A		
20 x 5 mm	319 A		
20 x 10 mm	497 A		
25 x 3 mm	287 A		
25 x 5 mm	384 A		
30 x 3 mm	337 A		
30 x 5 mm	447 A		
30 x 10 mm	676 A		
40 x 3 mm	436 A		
40 x 5 mm	573 A		
40 x 10 mm	850 A		
50 x 5 mm	697 A		
50 x 10 mm	1020 A		
60 x 5 mm	826 A		
60 x 10 mm	1180 A		
80 x 5 mm	1070 A		
80 x 10 mm	1500 A		
100 x 5 mm	1300 A		
100 x 10 mm	1810 A		
120 x 10 mm	2110 A		
160 x 10 mm	2700 A		

Copper busbar laminated	
Cross-section:	Current load:
6 x 13.0 x 0.5mm	150 A
6 x 15.5 x 0.8mm	290 A
10 x 24.0 x 1.0mm	600 A
10 x 32.0 x 1.0mm	800 A
10 x 40.0 x 1.0mm	950 A
10 x 50.0 x 1.0mm	1000 A
10 x 63.0 x 1.0mm	1240 A

Cable cross section Protective wire	
Cross-section Power supply:	min. Cross-section Protective wire:
S ≤ 16mm ²	S
16mm ² < S ≤ 35mm ²	16mm ²
S > 35mm ²	S / 2

General Project Information and Safety

General Instructions

This documentation is intended for the set-up and connection of the electric control unit by trained staff. Work on the control unit as well as commissioning and maintenance of the machinery must be carried out by qualified and trained staff.

The connection of the protective earth conductor is to be performed on site in compliance with the local regulations.

After transportation / before commissioning, all screw connections must be tightened (they may have worked loose).

To ensure proper cooling of the electric control unit the operator should regularly check the cooling equipment and clean or replace it if necessary (e.g. filter pads).

Safety-related components may only be replaced with equivalent components.

The present schematic diagram has been compiled using a CAD system. The arrangement of the components / connections must be adhered to precisely when installing the wiring.

Safety Instructions









It is not permitted to work on electrically live parts and equipment!



The machine may only be operated if all the protective devices are fitted in place and fully functional.

It is forbidden to remove the protective devices, bypass them or make them inoperative.


Should any of the protective devices show a fault, the machine must be stopped immediately and may only be started up again after repair has been carried out by qualified staff.

Terminal numbering














-60U7
EWO.FLEXY205
FLEXY 205
46




BxH: 1050mmx257mm
(Standard P15/P28 Montageplatte)








0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---



24VDC 2 General	24VDC 3 EMERGENCY STOP	24VDC 4 Interface 1
--------------------	---------------------------	------------------------

41.											51
V900	31.01.2024	ASCO	Date	11.05.2026	 ASCO Kohlenlaure AG Holenstrasse 19 CH-9300 Wittenbach +41 71 466 80 80 All about CO2 http://www.ascoco2.com	Page description: Voltage processing 24VDC feedback	Project-No.:	Project designation: Dry Ice Pelletizer: P15 EVO / P28 EVO CE US V531	= P15(i)_P28(i) = SS01		
			Editor					Scheme-No.:	Scheme-No. Customer: Project-No. Customer:	I sh	130
Modification	Date	Name								Pg	42




Doppelte Masseleitung erforderlich

WARNUNG
Für das F-PM-E 24VDC/8A PPM ST muss die Masseleitung zum BaseUnit aus Sicherheitsgründen doppelt verlegt werden. Ansonsten könnte bei der Unterbrechung einer einfachen Masseleitung die Potenzialschiene P2 nicht mehr sicherheitsgerichtet abgeschaltet werden.


0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

Siemens
-50KF51



0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

Signal tower blue +EXT-63X1:1	Signal tower green +EXT-63X1:2	Signal tower yellow +EXT-63X1:3	Signal tower red +EXT-63X1:4	Signal tower buzzer +EXT-63X1:5
Q1.3	Q1.4	Q1.5	Q1.6	Q1.7
/55.1	/55.1	/55.1	/55.1	
-50Kf41	-50Kf41	-50Kf41	-50Kf41	-50Kf41
DQ11	DQ11	DQ13	DQ14	DQ15



Interface 1 External Start / Stop (1 = start) (0 = Stop after end of cycle)	Interface 1 Drain Machine (1 = drain)	Interface 1 next batch (1 = next)	Interface 1 additional start condition (1 = approval)	Spare	Spare	Spare	Spare
12.0	12.1	12.2	12.3	Spare -66X1.7	Spare -66X1.8	Spare -66X1.9	Spare -66X1.10
/52.1	/52.1	/52.1	/52.1	12.4	12.5	12.6	12.7
-50KF25	-50KF25	-50KF25	-50KF25	/52.1	/52.1	/52.1	/52.1
D10	D11	D12	D13	-50KF25	-50KF25	-50KF25	-50KF25
1	2	3	4	D14	D15	D16	D17

41X7.13 / 41.7



+EXT

=R70i
Reformer R70i

Interface 1
External Start / Stop
(1 = start)
(0 = Stop after end of cycle)

Interface 1
Drain Machine
(1 = drain)

Interface 1
next batch
(1 = next)

Interface 1
additional start condition
(1 = approval)



Spare



4 1



3 2

OPTIONAL



+EXT

=R70i
Reformer R70i



Interface 1
Machine ready
(1 = ready)


Interface 1
Machine active
(1 = active)

Interface 1
Batch completed
(1 = completed)

Interface 1
Machine drained
(1 = empty)


OPTIONAL

Interface 1 Specification of production speed remotely (4...20mA = 0...100%)	
PIW110	
/5x1	
-50K32	
113+	UV3 113- 213+





0.14 mm² ... 1.5 mm²

+EXT




OPTIONAL





0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

Plant part 1 oil level +EXT-110B1:2
11.5
/51.1
-50KF21
D113


	Spare	Spare
	11.6	11.7
	/51.1	/51.1
	-50K721	-50K721
	D14	D15
	↑ 15	↑ 16




Plant part 1
oil level



70	V500	31.01.2024	ASCO	11.05.2026	 ASCO Kohlenlaure AG Hofenstrasse 19 CH-9300 Wittenbach +41 71 466 80 80 All about CO₂ http://www.ascoco2.com	Page description: Plant part 1 Sensors	Project-No.:	Project designation: Dry Ice Pelletizer P15 EVO / P28 EVO CE US V531	= P15()_P28() + SS01	120
								Scheme-No. Customer:	Project-No. Customer:	
								Scheme-No.:		130
	Modification	Date	Name						Pg	110





Parts list

Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks
=P15(0)_P28(0)	+SS01	-6U0	0				6;6.2	
=P15(0)_P28(0)	+SS01	-10Q5	1	CONTACTOR,AC3;7,5KW 1NO+1NC DC24V	Siemens	4070996	10	
=P15(0)_P28(0)	+SS01	-10Q5	1	SURGE SUPPRESSOR, VARISTOR,	Siemens	5003606	10	
=P15(0)_P28(0)	+SS01	-10Q5	1	AUX. SWITCH BLOCK , 4NO COND. PATHS: 1NO, 1NO,	Siemens	4065519	10	
=P15(0)_P28(0)	+SS01	-10Q6	1	CONTACTOR,AC3;7,5KW 1NO+1NC DC24V	Siemens	4070996	10	
=P15(0)_P28(0)	+SS01	-10Q6	1	SURGE SUPPRESSOR, VARISTOR,	Siemens	5003606	10	
=P15(0)_P28(0)	+SS01	-10Q6	1	AUX. SWITCH BLOCK , 4NO COND. PATHS: 1NO, 1NO,	Siemens	4065519	10	
=P15(0)_P28(0)	+SS01	-10X1	1	End bracket for terminal block	WAGO	4067670		
=P15(0)_P28(0)	+SS01	-10X1	1	End and partition plate for terminal block	Phoenix Contact	5003672		
=P15(0)_P28(0)	+SS01	-10X1	0				6	
=P15(0)_P28(0)	+SS01	-10X1	1	Ground terminal block	Phoenix Contact	5003671	10	
=P15(0)_P28(0)	+SS01	-10XD3	1	Verdrahtungsbaustein unten für Schutzkombination Baugröße S0	Siemens	4071480	10	
=P15(0)_P28(0)	+SS01	-15Q1	1	CIRCUIT-BREAKER SCREW CONNECTION 12.5A	Siemens	4044259	15	
=P15(0)_P28(0)	+SS01	-15Q1	1	TRANSVERSE AUX. SWITCH, 1NO+1NC, SCREW CONNECTION	Siemens	4064461	15	
=P15(0)_P28(0)	+SS01	-15Q2	1	SIRIUS SANFTSTARTER, S00,12.5A, 5,5KW/400V, 40GRAD, AC 200-480V, AC/DC 24V	Siemens	4070899	15	
=P15(0)_P28(0)	+SS01	-15X1	1	End bracket for terminal block	WAGO	4067670		
=P15(0)_P28(0)	+SS01	-15X1	1	End and partition plate for terminal block	Phoenix Contact	5003670		
=P15(0)_P28(0)	+SS01	-15X1	0				6	
=P15(0)_P28(0)	+SS01	-15X1	1	Multi-level terminal block	Phoenix Contact	5003669	15	
=P15(0)_P28(0)	+SS01	-15XD1	1	LINK MODULE 3RV2.1-3RT2.1,3RV2.2-3RT2.2	Siemens	5003673	15	
=P15(0)_P28(0)	+SS01	-15XD6	1	3-PHASE BUSBARS	Siemens	5003623	15	
=P15(0)_P28(0)	+SS01	-16Q1	1	CIRCUIT-BREAKER SCREW CONNECTION 0.32A	Siemens	4071000	16	
=P15(0)_P28(0)	+SS01	-16Q1	1	TRANSVERSE AUX. SWITCH, 1NO+1NC, SCREW CONNECTION	Siemens	4064461	16	
=P15(0)_P28(0)	+SS01	-16Q5	1	CONTACTOR,AC3;3KW 1NC DC24V	Siemens	4070997	16	
=P15(0)_P28(0)	+SS01	-16Q5	1	SURGE SUPPRESSOR, VARISTOR,	Siemens	4044411	16	
=P15(0)_P28(0)	+SS01	-16X1	1	End bracket for terminal block	WAGO	4067670		
=P15(0)_P28(0)	+SS01	-16X1	1	End and partition plate for terminal block	Phoenix Contact	5003670		
=P15(0)_P28(0)	+SS01	-16X1	0				6	

=P15(0)_P28(0)/130

Parts list

0	1	2	3	4	5	6	7	8	9
Parts list									
Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks	
=P15()_P28()	+SS01	-16X1	1	Multi-level terminal block	Phoenix Contact	5003669	16		
=P15()_P28()	+SS01	-16X1	1	Feed-through terminal block	Phoenix Contact	4067865	16		
=P15()_P28()	+SS01	-16XD1	1	LINK MODULE F.3RV S00/S0, 3RT S00	Siemens	4065520	16		
=P15()_P28()	+SS01	-40G1	1	Stromversorgung, 3-phasis	Lütze	4068174	40		
=P15()_P28()	+SS01	-40X1	1	End and partition plate for terminal block	Phoenix Contact	4067867	40		
=P15()_P28()	+SS01	-40X1	0				6		
=P15()_P28()	+SS01	-40X1	6	Feed-through terminal block	Phoenix Contact	4070909	40		
=P15()_P28()	+SS01	-40XT5	1	End bracket for terminal block	WAGO	4067670			
=P15()_P28()	+SS01	-40XT5	1	End and partition plate for terminal block	Phoenix Contact	4070910			
=P15()_P28()	+SS01	-40XT5	1	End and partition plate for terminal block	Phoenix Contact	5003672			
=P15()_P28()	+SS01	-40XT5	0				6		
=P15()_P28()	+SS01	-40XT5	1	Disconnect and test disconnect rail-mount terminal block	Phoenix Contact	4070911	40		
=P15()_P28()	+SS01	-40XT5	2	Ground terminal block	Phoenix Contact	5003671	40		
=P15()_P28()	+SS01	-41F1	1	Electronic device circuit breaker	Phoenix Contact	4065857	41		
=P15()_P28()	+SS01	-41F3	1	Electronic device circuit breaker	Phoenix Contact	4065857	41		
=P15()_P28()	+SS01	-41F5	1	Electronic device circuit breaker	Phoenix Contact	4065857	41		
=P15()_P28()	+SS01	-41F7	1	Electronic device circuit breaker	Phoenix Contact	4065857	41		
=P15()_P28()	+SS01	-41U0	1	Cross-connector for terminal block	Phoenix Contact	4071001			
=P15()_P28()	+SS01	-41X1	1	End bracket for terminal block	WAGO	4067670	41		
=P15()_P28()	+SS01	-41X1	1	End and partition plate for terminal block	Phoenix Contact	4067867	41		
=P15()_P28()	+SS01	-41X1	1	Cross-connector for terminal block	Phoenix Contact	4070908	41		
=P15()_P28()	+SS01	-41X1	0				6		
=P15()_P28()	+SS01	-41X1	3	Feed-through terminal block	Phoenix Contact	4070909	41		
=P15()_P28()	+SS01	-41X3	1	End and partition plate for terminal block	Phoenix Contact	4067867	41		
=P15()_P28()	+SS01	-41X3	1	Cross-connector for terminal block	Phoenix Contact	4070908	41		
=P15()_P28()	+SS01	-41X3	0				6		
=P15()_P28()	+SS01	-41X3	4	Feed-through terminal block	Phoenix Contact	4070909	41		
=P15()_P28()	+SS01	-41X5	1	End and partition plate for terminal block	Phoenix Contact	4067867	41		

Parts list

Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks
=P15(t)_P28(t)	+SS01	-41X5	1	Cross-connector for terminal block	Phoenix Contact	4070908	41	
=P15(t)_P28(t)	+SS01	-41X5	0				6	
=P15(t)_P28(t)	+SS01	-41X5	2	Feed-through terminal block	Phoenix Contact	4070909	41	
=P15(t)_P28(t)	+SS01	-41X7	1	End and partition plate for terminal block	Phoenix Contact	4067867	41	
=P15(t)_P28(t)	+SS01	-41X7	1	Cross-connector for terminal block	Phoenix Contact	4070908	41	
=P15(t)_P28(t)	+SS01	-41X7	0				6	
=P15(t)_P28(t)	+SS01	-41X7	3	Feed-through terminal block	Phoenix Contact	4070909	41	
=P15(t)_P28(t)	+SS01	-44F1	1	CIRCUIT BREAKER 10kA, 3POLE, C, 6A	Siemens	4068673	40	
=P15(t)_P28(t)	+SS01	-50A2	1	ET 200SP, BA 2XRJ45	Siemens	4068181	50	
=P15(t)_P28(t)	+SS01	-50A3	1	SIMATIC S7 Memory card 24 MB For S7-1x00 CPU	Siemens	4068182	50	
=P15(t)_P28(t)	+SS01	-50KF11	1	CPU 1512SP F-1 PN, 600KB Prog., 2MB Data	Siemens	4068180	50	
=P15(t)_P28(t)	+SS01	-50KF21	1	SIMATIC ET 200SP DI 16x 24V DC ST, PU 1	Siemens	4070341	50	
=P15(t)_P28(t)	+SS01	-50KF21	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2D	Siemens	4068190	50	
=P15(t)_P28(t)	+SS01	-50KF25	1	SIMATIC ET 200SP DI 16x 24V DC ST, PU 1	Siemens	4070341	50	
=P15(t)_P28(t)	+SS01	-50KF25	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2B	Siemens	4068191	50	
=P15(t)_P28(t)	+SS01	-50KF31	1	SIMATIC ET 200SP AI 2xU/I 2-/4-wire HS	Siemens	5003628	50	
=P15(t)_P28(t)	+SS01	-50KF31	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2B	Siemens	4068191	50	
=P15(t)_P28(t)	+SS01	-50KF32	1	SIMATIC ET 200SP AI 4xI 2-/4-wire ST	Siemens	4070340	50	
=P15(t)_P28(t)	+SS01	-50KF32	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2B	Siemens	4068191	50	
=P15(t)_P28(t)	+SS01	-50KF41	1	SIMATIC ET 200SP DQ 16x24 VDC/0.5 A ST	Siemens	4070342	50	
=P15(t)_P28(t)	+SS01	-50KF41	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2D	Siemens	4068190	50	
=P15(t)_P28(t)	+SS01	-50KF51	1	SIMATIC ET 200SP F-PM-E 24 V DC/8 A PPM ST	Siemens	4068188	50	
=P15(t)_P28(t)	+SS01	-50KF51	1	SIMATIC ET 200SP BU type C0 BU20-P6+A2+4D PU 1	Siemens	4068193	50	
=P15(t)_P28(t)	+SS01	-50KF52	1	SIMATIC ET 200SP DQ 8x24VDC/0.5A ST	Siemens	4068185	50	
=P15(t)_P28(t)	+SS01	-50KF52	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2B	Siemens	4068191	50	
=P15(t)_P28(t)	+SS01	-50KF53	1	SIMATIC ET 200SP DQ 4x24VDC/2A ST PU 1	Siemens	4071897	50	
=P15(t)_P28(t)	+SS01	-50KF53	1	SIMATIC ET 200SP BU type A0 BU15-P16+A0+2B	Siemens	4068191	50	
=P15(t)_P28(t)	+SS01	-60U7	1	Fernwartungsmodul	EWON	4066996	6	

Parts list

Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks
=P15()_P28()	+SS01	-60W2	1	Patch-Kabel LAN RJ45	GIGAMEDIA	4067623	60	
=P15()_P28()	+SS01	-61TF6	0				61	
=P15()_P28()	+SS01	-61TF8	0				61	
=P15()_P28()	+SS01	-61U7	1	Fernwartungsmodul	EWON	4066996	61	
=P15()_P28()	+SS01	-61U7	1	GSM Modul für Fernwartung	EWON	4070388_1	61	
=P15()_P28()	+SS01	-61U7	1	WLAN module for remote maintenance	EWON	4066997	61	
=P15()_P28()	+SS01	-61W5	1	Patch-Kabel LAN RJ45	GIGAMEDIA	4067312	61	
=P15()_P28()	+SS01	-61W6	1	Kabel zur WLAN Antenne 2m	EWON	4067196	61	
=P15()_P28()	+SS01	-61W8	1	Kabel zur 4G Antenne 3m	EWON		61	
=P15()_P28()	+SS01	-63W2.1	1	Assembled sensor actuator-line	Murrelektronik	4071269	63	
=P15()_P28()	+SS01	-63X2	0				63	
=P15()_P28()	+SS01	-65X1	1	End bracket for terminal block	WAGO	4067670		
=P15()_P28()	+SS01	-65X1	2	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-65X1	0				6	
=P15()_P28()	+SS01	-65X1	4	Feed-through terminal block	Phoenix Contact	4067865	65	
=P15()_P28()	+SS01	-65X1	1	Ground terminal block	Phoenix Contact	4067866	65	
=P15()_P28()	+SS01	-66X1	1	End bracket for terminal block	WAGO	4067670		
=P15()_P28()	+SS01	-66X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-66X1	0				6	
=P15()_P28()	+SS01	-66X1	8	Feed-through terminal block	Phoenix Contact	4067865	66;67	
=P15()_P28()	+SS01	-66X1	1	Ground terminal block	Phoenix Contact	4067866	67	
=P15()_P28()	+SS01	-67K1	1	Coupling relay, 1 changeover contact, 6A, 250V/AC	Finder	4071963	67	
=P15()_P28()	+SS01	-67K1	1	Socket, 12...24VDC, 1 Pole 6A, screw terminal	Finder	4044331	67	
=P15()_P28()	+SS01	-67K1	1	Relay interface module	Finder	4063743	6	
=P15()_P28()	+SS01	-67K2	1	Coupling relay, 1 changeover contact, 6A, 250V/AC	Finder	4071963	67	
=P15()_P28()	+SS01	-67K2	1	Socket, 12...24VDC, 1 Pole 6A, screw terminal	Finder	4044331	67	
=P15()_P28()	+SS01	-67K2	1	Relay interface module	Finder	4063743	6	
=P15()_P28()	+SS01	-67K3	1	Coupling relay, 1 changeover contact, 6A, 250V/AC	Finder	4071963	67	

Parts list

Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks
=P15()_P28()	+SS01	-67K3	1	Socket, 12...24VDC, 1 Pole 6A, screw terminal	Finder	4044331	67	
=P15()_P28()	+SS01	-67K3	1	Relay interface module	Finder	4063743	6	
=P15()_P28()	+SS01	-67K4	1	Coupling relay, 1 changeover contact, 6A, 250VAC	Finder	4071963	67	
=P15()_P28()	+SS01	-67K4	1	Socket, 12...24VDC, 1 Pole 6A, screw terminal	Finder	4044331	67	
=P15()_P28()	+SS01	-67K4	1	Relay interface module	Finder	4063743	6	
=P15()_P28()	+SS01	-68T1	1	Signal conditioner	Phoenix Contact	4070902	68	
=P15()_P28()	+SS01	-68W1.1	1	UL approved PVC Electronic cable LTY(C)Y (3x0,34) GY	Lütze	5003040	68	
=P15()_P28()	+SS01	-68W1.2	1	UL approved PVC Electronic cable LTY(C)Y (3x0,34) GY	Lütze	5003040	68	
=P15()_P28()	+SS01	-68X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-68X1	1	Feed-through terminal block	Phoenix Contact	4067865	68	
=P15()_P28()	+SS01	-68X1	1	Ground terminal block	Phoenix Contact	4067866	68	
=P15()_P28()	+SS01	-69SH2	1	Shield connection terminal	Weidmueller	4047811	69	
=P15()_P28()	+SS01	-69W3	1	UL approved PVC Electronic cable LTY(C)Y (3x0,34) GY	Lütze	5003040	69	
=P15()_P28()	+SS01	-69X1	1	End bracket for terminal block	WAGO	4067670		
=P15()_P28()	+SS01	-69X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-69X1	0				6	
=P15()_P28()	+SS01	-69X1	4	Feed-through terminal block	Phoenix Contact	4067865	69	
=P15()_P28()	+SS01	-69X1	1	Ground terminal block	Phoenix Contact	4067866	69	
=P15()_P28()	+SS01	-70K1	1	Relay interface module	Finder	4063743	70	
=P15()_P28()	+SS01	-70X1	1	End bracket for terminal block	WAGO	4067670		
=P15()_P28()	+SS01	-70X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-70X1	0				6	
=P15()_P28()	+SS01	-70X1	2	Feed-through terminal block	Phoenix Contact	4067865	70	
=P15()_P28()	+SS01	-70X1	1	Ground terminal block	Phoenix Contact	4067866	70	
=P15()_P28()	+SS01	-110X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15()_P28()	+SS01	-110X1	0				6	
=P15()_P28()	+SS01	-110X1	2	Feed-through terminal block	Phoenix Contact	4067865	110	
=P15()_P28()	+SS01	-110X1	1	Ground terminal block	Phoenix Contact	4067866	110	

Parts list

Plant	Mounting location	Device	Quantity	Designation	Manufacturer	Part number	Page	Remarks
=P15(i)_P28(i)	+S501	-110X3	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-110X3	0				6	
=P15(i)_P28(i)	+S501	-120X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-120X1	0				6	
=P15(i)_P28(i)	+S501	-120X1	4	Feed-through terminal block	Phoenix Contact	4067865	120	
=P15(i)_P28(i)	+S501	-120X1	1	Ground terminal block	Phoenix Contact	4067866	120	
=P15(i)_P28(i)	+S501	-120X5	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-120X5	0				6	
=P15(i)_P28(i)	+S501	-120X5	2	Feed-through terminal block	Phoenix Contact	4067865	120	
=P15(i)_P28(i)	+S501	-120X5	1	Ground terminal block	Phoenix Contact	4067866	120	
=P15(i)_P28(i)	+S501	-120X7	1	End bracket for terminal block	WAGO	4067670		
=P15(i)_P28(i)	+S501	-120X7	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-120X7	0				6	
=P15(i)_P28(i)	+S501	-120X7	1	Feed-through terminal block	Phoenix Contact	4067865	120	
=P15(i)_P28(i)	+S501	-120X7	1	Ground terminal block	Phoenix Contact	4067866	120	
=P15(i)_P28(i)	+S501	-120X9	2	Feed-through terminal block	Phoenix Contact	4067865	120	
=P15(i)_P28(i)	+S501	-120X9	1	Ground terminal block	Phoenix Contact	4067866	120	
=P15(i)_P28(i)	+S501	-130X1	1	End bracket for terminal block	WAGO	4067670		
=P15(i)_P28(i)	+S501	-130X1	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-130X1	2	Feed-through terminal block	Phoenix Contact	4067865	130	
=P15(i)_P28(i)	+S501	-130X1	2	Ground terminal block	Phoenix Contact	4067866	130	
=P15(i)_P28(i)	+S501	-130X5	1	End bracket for terminal block	WAGO	4067670		
=P15(i)_P28(i)	+S501	-130X5	1	End and partition plate for terminal block	Phoenix Contact	4067867		
=P15(i)_P28(i)	+S501	-130X5	2	Feed-through terminal block	Phoenix Contact	4067865	130	
=P15(i)_P28(i)	+S501	-130X5	2	Ground terminal block	Phoenix Contact	4067866	130	

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4068181	1	ET 200SP, BA 2XRJ45 SIMATIC DP, ET 200SP			
4068182	1	SIMATIC S7 Memory card 24 MB For S7-1x00 CPU Memory card			
4065857	4	Electronic device circuit breaker			
4068673	1	CIRCUIT BREAKER 10kA, 3POLE, C, 6A ACC. TO UL 489 - 480Y/277V			
4068174	1	Stromversorgung, 3-phasig 400-500VAC , 24VDC 20A , 480W			
4071963	4	Coupling relay, 1 changeover contact, 6A, 250VAC Modular interface relay, screw terminal - 1 pole, 6 A - AC (50/60 Hz)/DC - 24 V			
4044331	4	Socket, 12...24VDC, 1 Pole 6A, screw terminal			
4063743	5	Relay interface module Modular interface relay, screw terminal - 1 pole, 6 A - AC (50/60 Hz)/DC - 24 V			

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4066996	2	Fernwartungsmodul			
4070388_1	1	GSM Modul für Fernwartung 4G EU			
4066997	1	WLAN module for remote maintenance			
4067623	1	Patch-Kabel LAN RJ45 grün , 2m S/FTP Kat.6 LSOH			
4067312	1	Patch-Kabel LAN RJ45 grün , 1m S/FTP Kat.6 LSOH			
4067196	1	Kabel zur WLAN Antenne 2m			
	1	Kabel zur 4G Antenne 3m ???			
4071269	1	Assembled sensor actuator-line M12 Bu. 0° A-kod. freies Litg-ende PVC 8x0.25 gr UL/CSA 1m			



Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
5003040	3.00	UL approved PVC Electronic cable LIY(CY) (3×0,34) GY			
4067670	12	End bracket for terminal block Screwless end stop, 10 mm wide, for DIN-rail 35 x 15 and 35 x 7.5			
5003672	2	End and partition plate for terminal block End cover			
5003671	3	Ground terminal block Ground terminal			
5003670	2	End and partition plate for terminal block End cover			
5003669	2	Multi-level terminal block			
4067865	35	Feed-through terminal block Double-level terminal block			
4067867	18	End and partition plate for terminal block End cover			

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4070909	18	Feed-through terminal block Double-level terminal block			
4070908	4	Cross-connector for terminal block Plug-in bridge			
4067866	14	Ground terminal block Protective conductor double-level terminal block			
4071480	1	Verdrahtungsbaustein unten für Schützkomination Baugröße S0 ohne Abstand zwischen den Schützen, Schraubanschluss			
5003673	1	LINK MODULE 3RV2.1-3RT2.1,3RV2.2-3RT2.2 SIRIUS link module actuating voltage contactor: DC			
5003623	1	3-PHASE BUSBARS			
4065520	1	LINK MODULE F.3RV S00/S0, 3RT S00 SIRIUS link module for 3RV1.2 and 3RT101, for 3RV2.1/3RV2.2 and 3RT2.1			
4070910	1	End and partition plate for terminal block End cover			

1.5

V900	31.01.2024	ASCO	Date	12.05.2026	 ASCO Kohlenstaure AG Hohenstrasse 19 CH-8300 Wittenbach +41 71 466 80 80 http://www.ascoc2.com All about CO2	Page description: Summarized parts list		Project-No.:	Project designation: Dry Ice Pelletizer P15 EVO / P28 EVO CE US V531		= AUS02 + SS01		1.7
Modification	Date	Name	Editor					Scheme-No.	Project-No. Customer:	Project-No. Customer:	l sh	Pg	1.6

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4067780	1	SIMATIC HMI TP700 COMFORT SIMATIC, HMI Comfort Panel			
	0				
4063812	1	Disconnect switch 3-Pole, 25 A 600 V			
4067868	1	Main Switch Terminal Cover 3-pol ; 25A			
4063813	1	Handle for Front/Base Mounting, 67 x 67mm			
4063814	1	Shaft Extension			
4071240	1	ILLUMINATED PUSHBUTTON, BLUE SIRIUS ACT CIN20240911110240188284			
4071233	2	HOLDER SIRIUS ACT Holders Holder			

+5501/L7

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4071241	1	CONTACT MODULE 1NO SIRIUS ACT Contact module Contact module			
4071242	1	LED MODULE, BLUE SIRIUS ACT LED module LED module			
4071232	1	ILL. EM. STOP MUSHR. PUSHBUTTON, 40MM, RED SIRIUS ACT EMERGENCY STOP mushroom pushbuttons Betätigungs-/Meldeelement			
4071237	2	CONTACT MODULE 1NC SIRIUS ACT Contact module Contact module			
4071238	1	LED MODULE, RED SIRIUS ACT LED module LED module			
4071239	1	EMERGENCY STOP BACKING PLATE, YELLOW SIRIUS ACT EMERGENCY STOP backing plate EMERGENCY STOP name plate			

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

Summarized parts list

ASCO_F02_006

Order number	Quantity	Designation	Type number	Manufacturer	Image
4044263	1	Directional Valve 24VDC 38W			
4065745	2	Magnetventil 24V 20W			

Cable name

=P15(i)_P28(i)+SS01-69W3

Cable type

3x0,34 mm²

Free conductors

1

ASCO CO2 Detector

Manufacturer Lütze

Order number 5003040

Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number
Control cabinet	-69X1:4:2	ASCO CO2 Detector			
Control cabinet	-69X1:3:1	=			
Control cabinet	-69S42:5H	ASCO CO2 Detector			

Part number	L2 [mm]	Stopper	Function text target	Target	Mounting location:
			ASCO CO2 Detector	-50KF32:7	Control cabinet
			=	-50KF32:3	Control cabinet
			ASCO CO2 Detector	-69W3:5H	Control cabinet

Cable name

=P15(i)_P28(i)+EXT-10W1

Cable type

4x4 mm²

Free conductors

0

Power supply

Manufacturer Lütze

Order number 5003033

Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number
Door	+DR-10Q1:1	Main switch			
Door	+DR-10Q1:3	=			
Door	+DR-10Q1:5	=			
Control cabinet	+SS01-10X1:1:1	Power supply			

Part number	L2 [mm]	Stopper	Function text target	Target	Mounting location:
			Main switch	L1	
			=	L2	
			=	L3	
			Power supply	PE	

Cable name

=P15(i)_P28(i)+EXT-16W1

Cable type

7x0,5 mm²

Free conductors

1

Hydraulic motor 1 Fan

Manufacturer Lütze

Order number 5003568

Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number
Control cabinet	+SS01-16X1:2:6	Hydraulic motor 1 Fan			
Control cabinet	+SS01-16X1:1:5	=			
Control cabinet	+SS01-16X1:3:7	=			
Control cabinet	+SS01-16X1:5:4	Hydraulic motor 1 Fan			
Control cabinet	+SS01-16X1:6:3	=			
Control cabinet	+SS01-16X1:4:1	=			

Part number	L2 [mm]	Stopper	Function text target	Target	Mounting location:
			Hydraulic motor 1 Fan	-16M1:U	External
			=	-16M1:V	External
			=	-16M1:W	External
			Hydraulic motor 1 Fan	-16M1:RD	External
			=	-16M1:RD	External
			=	-16M1:PE	External

0

1

2

3

4

5

6

7

8

9

Cable name

Cable type

Free conductors

=P15(i)_P28(i)+EXT-61W9

8x0,25 mm²

8

remote maintenance module (VPN)

Mounting location:

Source

Function text source

Stopper

L1 [mm]

Part number

WH1

WH2

WH3

WH4

WH5

WH6

WH7

WH8

L1

L2

2 m

-61W9

WH1

WH2

WH3

WH4

WH5

WH6

WH7

WH8

L2

Mounting location:

Target

Manufacturer

Order number

Rittal

4071505

Cable name

Cable type

Free conductors

=P15(i)_P28(i)+EXT-63W2.2

8x0,25 mm²

2

Mounting location:

Source

Function text source

Stopper

L1 [mm]

Part number

WH

BN

GN

YE

GY

PK

BU

RD

L1

L2

0.6 m

-63W2.2

WH

BN

GN

YE

GY

PK

BU

RD

L2

Mounting location:

Target

Manufacturer

Order number

Murrelektronik

4071270

1.2

V900

31.01.2024

ASCO

Date

11.05.2026

Editor

Modification

Date

Name

Page description:

Cable diagram

ASCO Kohlenstaure AG

Höhenstrasse 19

CH-8300 Wittenbach

+41 71 466 80 80

info@www.ascoco2.com

Project-No.:

Scheme-No.:

Project designation:

Dry Ice Pelletizer P15 EVO / P28 EVO CE US V531

Scheme-No. Customer:

Project-No. Customer:

= AU503

+

1.4





1.6

1.3

Free conductors 3					
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number
Control cabinet	+SS01-69X1:1:4	ASCO CO2 Detector			
Control cabinet	+SS01-69X1:2:3	=			
Control cabinet	+SS01-69X1:3:4	=			
Control cabinet	+SS01-69X1:4:3	=			
Control cabinet	+SS01-69X1:5:4	ASCO CO2 Detector			
Control cabinet	+SS01-69X1:6:3	=			
Control cabinet	+SS01-69X1:7:4	=			
Control cabinet	+SS01-69X1:8:3	=			
Control cabinet	+SS01-69X1:9:4	ASCO CO2 Detector			
Control cabinet	+SS01-69X1:10:3	=			

Cable name =P15(i)_P28(i)+EXT-110W1										Plant part 1 oil level										Manufacturer Lapp Group			
Cable type 2x0.75 mm																				Order number 5002883			
Free conductors 0																							
Mounting location:		Source		Function text source		Stopper		L1 [mm]		Part number		L2 [mm]		Stopper		Function text target		Target		Mounting location:			
Control cabinet		+SS01-1-10X1:1:4		Plant part 1 oil level						1		1				Plant part 1 oil level		-110B1:1		External			
Control cabinet		+SS01-1-10X1:2:3		=						2		2				=		-110B1:2		External			

[illegible]

Plant part 1 pressure measurement hydraulic									
Cable name =P15(i)_P28(i)+EXT-120W5 Cable type 4x0,34 mm² Free conductors 0			Manufacturer Murrelektronik Order number 4071188						
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number				
Control cabinet	+SS01-120X5:1:4	Plant part 1 pressure measurement							
Control cabinet	+SS01-120X5:2:3	=							
Control cabinet	+SS01-120X5:3:4	=							
Control cabinet	+SS01-120X5:4:3	=							
Control cabinet	+SS01-120X5:6:3	=							
						Part number	Stopper	Function text target	Target
								Plant part 1 pressure measurement	-120B5:1
								=	-120B5:2
								=	-120B5:3
								=	-120B5:4
								=	-120W5:SH
Plant part 1 Pressure measurement CO2									
Cable name =P15(i)_P28(i)+EXT-120W7 Cable type 4x0,34 mm² Free conductors 2			Manufacturer Murrelektronik Order number 4071188						
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number				
Control cabinet	+SS01-120X7:1:4	Plant part 1 Pressure measurement							
Control cabinet	+SS01-120X7:2:3	Plant part 1 Pressure measurement							
Control cabinet	+SS01-120X7:4:3	Plant part 1 Hydraulic oil temperature							
						Part number	Stopper	Function text target	Target
								Plant part 1 Pressure measurement	-120B7:1
								Plant part 1 Pressure measurement	-120B7:3
								Plant part 1 Hydraulic oil temperature	-120W7:SH
Plant part 1 Hydraulic oil temperature									
Cable name =P15(i)_P28(i)+EXT-120W9 Cable type 4x0,34 mm² Free conductors 0			Manufacturer Murrelektronik Order number 4071188						
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number				
Control cabinet	+SS01-120X9:1:4	Plant part 1 Hydraulic oil temperature							
Control cabinet	+SS01-120X9:2:3	=							
Control cabinet	+SS01-120X9:3:4	=							
Control cabinet	+SS01-120X9:4:3	=							
Control cabinet	+SS01-120X9:6:3	=							
						Part number	Stopper	Function text target	Target
								Plant part 1 Hydraulic oil temperature	-120B9:1
								=	-120B9:2
								=	-120B9:3
								=	-120B9:4
								=	-120W9:SH
Plant part 1 CO2 valve 1									
Cable name =P15(i)_P28(i)+EXT-130W1 Cable type 3x0,5 mm² Free conductors 0			Manufacturer Lütze Order number 5003631						
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number				
Control cabinet	+SS01-130X1:1:4	Plant part 1 CO2 valve 1							
Control cabinet	+SS01-130X1:2:3	=							
Control cabinet	+SS01-130X1:3:4	=							
						Part number	Stopper	Function text target	Target
								Plant part 1 CO2 valve 1	-130X1
								=	-130X1
								=	-130X1

00

31.01.2024

ASCO

Date

11.05.2026

Editor

Name

Date

Page description:

ASCO Kohlschüre AG
Hofenstrasse 19
CH-9300 Wittenbach
+41 71 466 80 80
http://www.ascoco2.com

Cable diagram


Project designation:


Dry Ice Pelletizer P15 EVO / P28 EVO CE US V531


Project No.

Customer:

</

Cable name =P15(i)_P28(i)+EXT-130W3					Plant part 1 CO2 valve 2					Manufacturer Lütze	
Cable type 3x0,5 mm²										Order number 5003631	
Free conductors 0											
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number						
Control cabinet	+SS01-1-130X15:4	Plant part 1 CO2 valve 2									
Control cabinet	+SS01-1-130X16:3	=									
Control cabinet	+SS01-1-130X17:4	=									
							Part number	Stopper	Function text target	Target	Mounting location:
									Plant part 1 CO2 valve 2	-130X3	External
									=	-130X3	External
									=	-130X3	External

Cable name =P15(i)_P28(i)+EXT-130W5					Plant part 1 valve forward					Manufacturer Murrelektronik	
Cable type 3x0,75 mm²										Order number 4066062	
Free conductors 0											
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number						
Control cabinet	+SS01-1-130X5:1:4	Plant part 1 valve forward									
Control cabinet	+SS01-1-130X5:2:3	=									
Control cabinet	+SS01-1-130X5:3:4	=									
						Part number	Stopper	Function text target	Target	Mounting location:	
								Plant part 1 valve forward	-130Y5:A1	External	
								=	-130Y5:A2	External	
								=	-130Y5:PE	External	

Cable name =P15(i)_P28(i)+EXT-130W7					Plant part 1 valve backward					Manufacturer Murrelektronik		Order number 4066062	
Cable type 3x0,75 mm²													
Free conductors 0													
Mounting location:	Source	Function text source	Stopper	L1 [mm]	Part number							Target	Mounting location:
Control cabinet	+SS01-1-130X5:5-4	Plant part 1 valve backward										-130Y7:A1	External
Control cabinet	+SS01-1-130X5:6-3	=										-130Y7:A2	External
Control cabinet	+SS01-1-130X5:7-4	=										-130Y7:PE	External

Terminal diagram

function text	Terminal strip =P15(i)_P28(i)+SS01 -40X1 0VDC										Cable name	cable type	Connection point	Target designation Internal	jumper	Level	terminal	Connection point	Target designation External	Cable name	cable type	function text																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										

Terminal diagram

function text	Terminal strip =P15(i)_P28(i)+SS01 -41X3 24VDC 2										Cable name												Page / column
	cable type		Connection point		terminal		Level		jumper		Target designation Internal		Connection point										
24VDC General			+DR-60S5		13	2	1	1	0		-41F3		2.1								/41.3		
			-10Q5		21	3																	
			-50KF41		L+	4																	
24VDC General			40G1		11	2	2	1	0		-15Q1		13								/41.3		
			-15Q2		A1	3																	
			-16Q5		21	4																	
24VDC General			-120X1		1:1	2	3	1	0		-110X1		1:1								/41.3		
			-16X1		5:1	4																	
			-50KF21		3	4	4	0	0												/41.4		
24VDC EMERGENCY STOP																							

Terminal diagram

function text		Cable name		Terminal strip =P15(i)_P28(i)+SS01 -41X5 24VDC 3										Cable name		cable type		Page / column	
24VDC EMERGENCY STOP				Target designation External		Connection point		terminal		Level		jumper		Target designation Internal		Connection point			
				-50KF51		1L		4 1		1		•				2.1			
				-50KF21		4		4 2		0								/41.5	
=																		/41.5	

Terminal diagram

Terminal strip =P15(i)_P28(i)+SS01 -66X1 Interface 1													Page / column	
Cable name	cable type											Page / column		
function text	Connection point	terminal	Level	jumper	Target designation Internal	Connection point	Cable name					Page / column		
		4 1 1 1	1	•	-41X7	1:3						/66.0		
		2	2	•								/66.0		
	Interface 1 External Start / Stop (1 = start) (0 = Stop after end of cycle)	4 3 1 1	1	•	-50KF25	1						/66.1		
	Interface 1 Drain Machine (1 = drain)	3 4 2 2	2	•	-50KF25	2						/66.2		
	Interface 1 next batch (1 = next)	4 5 1 1	1	•	-50KF25	3						/66.3		
	Interface 1 additional start condition (1 = approval)	3 6 2 2	2	•	-50KF25	4						/66.4		
	Spare	7 1 1	1	•	-50KF25	5						/66.5		
	=	8 2 2	2	•	-50KF25	6						/66.6		
	=	9 1 1	1	•	-50KF25	7						/66.7		
	=	10 2 2	2	•	-50KF25	8						/66.8		
		11 1 1	1	•	-67K1	11						/67.0		
		12	2	•								/67.0		
	Interface 1 Machine ready (1 = ready)	13 1 1	1	•	-67K1	14						/67.1		
	Interface 1 Machine active (1 = active)	14 2 2	2	•	-67K2	14						/67.2		
	Interface 1 Batch completed (1 = completed)	15 1 1	1	•	-67K3	14						/67.3		
	Interface 1 Machine drained (1 = empty)	16 2 2	2	•	-67K4	14						/67.4		
	=	17	1	•								/67.4		
=	18	2	•								/67.5			

Terminal diagram

function text	Terminal strip =P15(i)_P28(i)+SS01 -70X1 Interface 1 conveyor belt												Page / column
	Cable name	cable type											
	Cable name	cable type	Connection point	Target designation External	terminal	Level	jumper	Target designation Internal	Connection point				

Terminal diagram

function text	Terminal strip =P15(i)_P28(i)+SS01 -130X1 Plant part 1 CO2 valve 1										Page / column
	Cable name		cable type						Connection point		

Terminal diagram

Terminal strip =P15(i)_P28(i)+SS01 -40XT5 Power supply unit Disconnect terminal																	Cable name																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	------------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Terminal line-up diagram

Hydraulic motor 1
Fan

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3210443
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3210443	D-PT 4-PE/3L				
PXC.3210442	PT 4-PE/3L				
PXC.3214657	PTTBS 1,5/S	1.5			

=P15(i)_P28(i)
+SS01
-16X1


						
						
'	1					
'	2					
'	3					
	4					
'	5					
'	6					

Terminal line-up diagram

0VDC

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			

=P15(i)_P28(i)
+SS01
-40X1




Terminal line-up diagram

24VDC 1

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			

=P15(i)_P28(i)
+SS01
-41X1




Terminal line-up diagram

24VDC 2

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			
PXC.3214686	PTTBS 1,5/S-PV	1.5			

=P15(i)_P28(i)
+SS01
-41X3



Terminal line-up diagram

Interface 1
Emergency stop

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			

=P15(i)_P28(i)
+SS01
-65X1

'	1								
'	2								
'	3								
'	4								
'	5								
'	6								
•	7								
•	8								
•	9								
•	10								

Terminal line-up diagram

Interface 1

Part number						
Mounting rail			Strip label	End angle rear	End plate	
				WAGO.249-117	PXC.3214699	
Terminal						
Part number	Type number	Cross-section	Terminal label	Jumper	Cover	
WAGO.249-117	249-117					
PXC.3214699	D-PTTBS 1,5/S					
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				

=P15(i)_P28(i)
+SS01
-66X1


					
					
'	1				
'	2				
'	3				
'	4				
'	5				
'	6				
'	7				
'	8				
'	9				
'	10				
'	11				

Terminal line-up diagram

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

Interface 1

=P15(i)_P28(i)
+SS01
-66X1


'	12	
'	13	
'	14	
'	15	
'	16	
'	17	
'	18	

Terminal line-up diagram

Interface 1

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-68X1

				
1				
2				
3				
4				

Terminal line-up diagram

Interface 1
ASCO CO2 detector

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-69X1

					
					
'	1				
'	2				
'	3				
'	4				
'	5				
'	6				
'	7				
'	8				
'	9				
'	10				

Terminal line-up diagram

Interface 1
conveyor belt

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-70X1

					
					
!	1				
!	2				
!	3				
!	4				
!	5				
!	6				

Terminal line-up diagram

Plant part 1
oil level

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-110X1

'	1				
'	2				
'	3				
'	4				
'	5				
'	6				

Terminal line-up diagram

Plant part 1
linear measurement

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-120X1



'	1								
'	2								
'	3								
'	4								
'	5								
'	6								
'	7								
'	8								
'	9								
'	10								

Terminal line-up diagram

Plant part 1
pressure measurement hydraulic

Part number					
Mounting rail			Strip label	End angle rear	End plate
					PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			


=P15(i)_P28(i)
+SS01
-120X5

'	1				
'	2				
'	3				
'	4				
'	5				
'	6				

Terminal line-up diagram

Part number					
Mounting rail			Strip label	End angle rear	End plate
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-120X9

'	1	
'	2	
'	3	
'	4	
'	5	
'	6	

Terminal line-up diagram

Plant part 1
CO2 valve 1

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3214699
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3214699	D-PTTBS 1,5/S				
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			
PXC.3214657	PTTBS 1,5/S	1.5			
PXC.3214673	PTTBS 1,5/S-PE	1.5			

=P15(i)_P28(i)
+SS01
-130X1

					
					
'	1				
'	2				
'	3				
'	4				
'	5				
'	6				
'	7				
'	8				



Terminal line-up diagram

Plant part 1
valve forward

Part number						
Mounting rail			Strip label	End angle rear	End plate	
				WAGO.249-117	PXC.3214699	
Terminal						
Part number	Type number	Cross-section	Terminal label	Jumper	Cover	
WAGO.249-117	249-117					
PXC.3214699	D-PTTBS 1,5/S					
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214673	PTTBS 1,5/S-PE	1.5				
PXC.3214657	PTTBS 1,5/S	1.5				
PXC.3214673	PTTBS 1,5/S-PE	1.5				

=P15(i)_P28(i)
+SS01
-130X5

					
					
'	1				
'	2				
'	3				
'	4				
'	5				
'	6				
'	7				
'	8				

Terminal line-up diagram


Power supply unit
Disconnect terminal

Part number					
Mounting rail			Strip label	End angle rear	End plate
				WAGO.249-117	PXC.3211003;PXC.3208979
Terminal					
Part number	Type number	Cross-section	Terminal label	Jumper	Cover
WAGO.249-117	249-117				
PXC.3211003	D-PT 2,5-MT				
PXC.3208979	D-PT 4-QUATTRO				
PXC.3210156	PT 2,5-MT	4			
PXC.3211809	PT 4-QUATTRO-PE	6			
PXC.3211809	PT 4-QUATTRO-PE	6			

=P15(i)_P28(i)
+SS01
-40XT5

					
					
					
	1				
	2				
	3				

HYDRAULIC

[illegible]

Umgebungstemperatur : 0-40 °C
Ölreinheit : 19/17/14 ISO 4406
Öltyp : Mineralöl
Verschraubungssystem: DIN EN ISO 8434-1, Schneidring, verzinkt